

Thank you for choosing this Icom product.
This channel list shows factory preset frequencies and names. If your transceiver containing different frequencies, your dealer may have a print out of frequencies entered into the transceiver.

Frequency unit: all in kHz

Emergency frequency list

	Radiotelephone	DSC
MF	2182.0	2187.5
HF4	4125.0	4207.5
HF6	6215.0	6312.5
HF8	8291.0	8414.5
HF12	12290.0	12577.0
HF16	16420.0	16804.5

User channels (Dealer settable)

Channel No.	RX frequency	TX frequency	Mode	Channel name
1	2182.0	←	J3E	EMERGENCY
2	4125.0	←	J3E	EMERGENCY
3	6215.0	←	J3E	EMERGENCY
4	8291.0	←	J3E	EMERGENCY
5	12290.0	←	J3E	EMERGENCY
6	16420.0	←	J3E	EMERGENCY
7*1	5000.0		H3E	WWW
8*1	10000.0		H3E	WWW
9*1	15000.0		H3E	WWW
10	2450.0	2003.0	J3E	
11	2506.0	2406.0	J3E	
12	4357.0	4065.0	J3E	
13	4402.0	4110.0	J3E	
14	4405.0	4113.0	J3E	
15	8728.0	8204.0	J3E	
16	8743.0	8219.0	J3E	
17	8782.0	8258.0	J3E	
18	13077.0	12230.0	J3E	
19	13080.0	12233.0	J3E	
20	13083.0	12236.0	J3E	
21	17245.0	16363.0	J3E	
22	17248.0	16366.0	J3E	
23	17311.0	16429.0	J3E	
24	22735.0	22039.0	J3E	
25	22762.0	22066.0	J3E	
26	22777.0	22081.0	J3E	
27	22801.0	22105.0	J3E	
28	2490.0	2031.5	J3E	
29	2442.0	2406.0	J3E	
30	2514.0	2118.0	J3E	
31	2566.0	2390.0	J3E	
32	4363.0	4071.0	J3E	
33	4390.0	4098.0	J3E	
34	4405.0	4113.0	J3E	
35	4423.0	4131.0	J3E	
36	8722.0	8198.0	J3E	
37	8731.0	8207.0	J3E	
38	8746.0	8222.0	J3E	
39	8758.0	8234.0	J3E	
40	8791.0	8267.0	J3E	

*1 RX only

Channel No.	RX frequency	TX frequency	Mode	Channel name
41	8809.0	8285.0	J3E	
42	13092.0	12245.0	J3E	
43	13098.0	12251.0	J3E	
44	13101.0	12254.0	J3E	
45	13119.0	12272.0	J3E	
46	13143.0	12296.0	J3E	
47	13164.0	12317.0	J3E	
48	17242.0	16360.0	J3E	
49	17266.0	16384.0	J3E	
50	17269.0	16387.0	J3E	
51	17272.0	16390.0	J3E	
52	17287.0	16405.0	J3E	
53	22738.0	22042.0	J3E	
54	22741.0	22045.0	J3E	
55	22759.0	22063.0	J3E	
56	2450.0	2366.0	J3E	
57	2558.0	2166.0	J3E	
58	2561.0	2169.0	J3E	
59	4384.0	4092.0	J3E	
60	4387.0	4095.0	J3E	
61	4402.0	4110.0	J3E	
62	4420.0	4128.0	J3E	
63	8740.0	8216.0	J3E	
64	8749.0	8225.0	J3E	
65	8761.0	8237.0	J3E	
66	8794.0	8270.0	J3E	
67	13083.0	12236.0	J3E	
68	13104.0	12257.0	J3E	
69	13107.0	12260.0	J3E	
70	13158.0	12311.0	J3E	
71	17254.0	16372.0	J3E	
72	17299.0	16417.0	J3E	
73	17317.0	16435.0	J3E	
74	17332.0	16450.0	J3E	
75	22696.0	22000.0	J3E	
76	22708.0	22012.0	J3E	
77	22723.0	22027.0	J3E	
78	22801.0	22105.0	J3E	
79	2065.0	←	J3E	
80	2079.0	←	J3E	

Channel No.	RX frequency	TX frequency	Mode	Channel name
81	2096.5	←	J3E	
82*1	3023.0	←	J3E	
83	4125.0	←	J3E	
84	4164.0	←	J3E	
85	4149.0	←	J3E	
86	4417.0	←	J3E	
87*1	5680.0	←	J3E	
88	6224.0	←	J3E	
89	6227.0	←	J3E	
90	6230.0	←	J3E	
91	6516.0	←	J3E	
92	8294.0	←	J3E	
93	8297.0	←	J3E	
94	12353.0	←	J3E	
95	12356.0	←	J3E	
96	12359.0	←	J3E	
97	16528.0	←	J3E	
98	16531.0	←	J3E	
99	16534.0	←	J3E	
100	18840.0	←	J3E	
101	18843.0	←	J3E	
102	22159.0	←	J3E	
103	22162.0	←	J3E	
104	22165.0	←	J3E	
105	22168.0	←	J3E	
106	22171.0	←	J3E	
107	25115.0	←	J3E	
108	25118.0	←	J3E	
109	2070.5	←	J3E	
110	2072.5	←	J3E	
111	2074.5	←	J3E	
112	2076.5	←	J3E	
113	4154.5	←	J3E	
114	4169.5	←	J3E	
115	6235.5	←	J3E	
116	6259.5	←	J3E	
117	8302.5	←	J3E	
118	8338.5	←	J3E	
119	12370.4	←	J3E	
120	12418.5	←	J3E	
121	16551.5	←	J3E	
122	16614.5	←	J3E	
123	18847.5	←	J3E	
124	18868.5	←	J3E	
125	22181.5	←	J3E	
126	22238.5	←	J3E	
127	25123.5	←	J3E	
128	25159.5	←	J3E	
129	2003.0	←	J3E	
130	2006.0	←	J3E	
131	2030.0	←	J3E	
132	2054.0	←	J3E	
133	2065.0	←	J3E	
134	2079.0	←	J3E	
135	2082.5	←	J3E	

Channel No.	RX frequency	TX frequency	Mode	Channel name
136	2086.0	←	J3E	
137	2093.0	←	J3E	
138	2096.5	←	J3E	
139	2115.0	←	J3E	
140	2118.0	←	J3E	
141	2134.0	←	J3E	
142	2142.0	←	J3E	
143	2182.0	←	J3E	
144	2203.0	←	J3E	
145	2419.0	←	J3E	
146	2422.0	←	J3E	
147	2427.0	←	J3E	
148	2430.0	←	J3E	
149	2447.0	←	J3E	
150	2450.0	←	J3E	
151	2479.0	←	J3E	
152	2482.0	←	J3E	
153	2506.0	←	J3E	
154	2509.0	←	J3E	
155	2527.0	←	J3E	
156	2535.0	←	J3E	
157	2638.0	←	J3E	
158	2738.0	←	J3E	

